








# Solar PV Water Heater Quick Reference Guide



Dial Setting	Time on Mains*	Time on Solar*	24-Hour Clock
<b>MAINS ONLY</b>	24 hr	Never	
<b>1</b>	12:00 to 08:00	08:00 to 12:00	
<b>2</b>	14:30 to 05:30	05:30 to 14:30	
<b>3</b>	17:00 to 03:00	03:00 to 17:00	
<b>SOLAR ONLY</b>	Never	24 hr	

\* Times are approximate – will vary slightly with season and location

< Attach Elon Serial Number Label Here >

Lights	Meaning
	<b>Green light ON</b> <b>Geyser on temperature</b>
	<b>Green light flashing</b> Heating with solar
	<b>Red light ON</b> Mains power available (power to Elon® unit on)
	<b>Red light flashing</b> Heating with mains
	<b>Red &amp; Green light flashing fast</b> Isolation fault (contact electrician)
	<b>Both lights OFF</b> No power to unit (for example: no sun plus a power failure, or no sun plus geyser breaker at DB board is switched off) OR supply voltage outside specifications

Online user instruction video:

 [www.poweroptimal.com/elon100](http://www.poweroptimal.com/elon100)

Full user manual:

 [www.poweroptimal.com/manuals](http://www.poweroptimal.com/manuals)

V 2.06

2020/11/23